



1-7 (1-7) 8 (8-16) 9 (17-23) 10 (24-33) 11 (34-43) 12 (44-51) 13 (52-59)

14 (60-66) 15 (67-78) 16 (79-83) 17 (84-87) 18 (88-96) 19 (97-107)

COLORS

1. 請依照零件包內的插圖或零件清單所列的顏色位置，儘量正確地進行。
 Please refer to the color codes carefully when carrying out the color codes in the instruction manual.
 仔細依照零件包內的插圖，或零件清單所列的顏色位置，儘量正確地進行。務必遵照指示。

20 21

22 23

24 25 26

27 28

29 30

31 32 33

34 35

36 37

38 39

40 41

42 43

44 45

46 47

48 49

50 51

52 53

54 55

56 57

58 59

60 61

62 63

64 65

66 67

68 69

70 71

72 73

74 75

76 77

78 79

80 81

82 83


84 85

86 87

88 89

90 91

92 93



1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

A vertical strip of 67 numbered steps from a LEGO assembly manual. Each step includes a small inset image showing the required parts and their part numbers, and a larger main image showing the assembly process. The steps are arranged in two columns, with step numbers 1-16 on the left and 17-32 on the right, 33-48 on the left, and 49-67 on the right. The instructions show the gradual construction of the jet's fuselage, wings, and tail, culminating in the final assembly of the canopy and the completed model.